



1. REMOVE "BLUE" WIRE FROM CENTER TAP OF RHEOSTAT - CONNECT TO CENTER TAP OF TOGGLE
2. INSTALL NEW WIRE FROM TOP OF TOGGLE TO CENTER TAP OF RHEOSTAT
3. INSTALL SPADE PIGGYBACK TERMINAL ON GREEN WIRE FROM PIGTAIL, CONNECT TO "B" TERMINAL AT PC BOARD. ATTACH BLACK WIRE FROM RECEPT TO PIGGYBACK
4. WHITE WIRE FROM PIGTAIL TO BOTTOM TAP OF TOGGLE
5. BLACK WIRE FROM PIGTAIL TO OUTSIDE TAP OF RHEOSTAT (AS PICTURED)
6. FEMALE PIGTAIL PLUG: BLACK WIRE TO BRASS SCREW, GREEN WIRE TO SILVER SCREW, WHITE WIRE TO GREEN SCREW